


Bamocks loftsophæng til slyngevugge

BRUGERMANUAL

Stykliste



Nylonbelagt rustfrit stål O-loftskrog med gummibelagt karabinhage. Medfølgende Fischer rawplug



Justerbar forlængerstrop i GOTS certificeret økologisk bomuld

Monteringsvejledning

Montering i træloft/spær

Inden montering i træloft skal du sikre dig at pladetykkelsen på træloftet er minimum 12,5 mm. Sikre dig ligeledes at træloftet er stabilt og stærkt. Monter ikke på gipsloft, medmindre der er træspær direkte under det punkt der skrues.

- 1 Brug et Ø5 mm træbor til at bore et hul på 40 mm dybde i loftet. Hvis du ikke har en træbor, kan du bruge en en skruetrækker og en hammer. Bank forsigtigt skruetrækkeren for at lave et lille hul i træloftet, hvor du kan skruer loftkrogen fast
- 2 Skru loftkrogen i loftet, indtil den sidder fast og du ikke kan se skrueerne mere.
- 3 Sæt karabinhagen fast på loftkrogen ved at åbne karabinhagen og hæfte den ind i øjet på loftskrogen.
- 4 Montér nu vuggemotor eller fjeder på karabinhagen. Hvis afstanden mellem slyngevuggen og gulvet er for høj, kan du justere den med den medfølgende strop. Montér først stroppen på vuggemotor eller fjeder og derefter skal den hæftes på loftskroget.


Afprøv loftskrogen med karabinhagen og slyngevuggen ved at lægge vægt på 15-20 kg. i slyngevuggen. Tjek om loftskrogen kan bære vægten uden at bevæge sig eller glide ud af loftet. Hvis loftskrogen bevæger sig, skal du skramme skrueerne eller vælge en anden placering på loftet.

Montering i betonlofter


Inden monteringen i betonloft skal du sikre dig, at din betonloft er solid. Du skal bruge en beton boremaskine og et Ø8 betonbor

- 1 Brug et Ø8 betonbor til at bore et hul på min. 40 mm
- 2 Montér Fischer-pluggen i hullet
- 3 Skru loftskroget i Fischer pluggen indtil du ikke længere kan se skrueerne. Efterfølgende indsættes karabinhagen på loftskroget

Kontrollér at loftskroget sidder godt fast i Fischer-pluggen og afprøv installationen med 15-20 kg. for at sikre at loftskroget slet ikke bevæger sig når den er afprøvet.



Brug et Ø5 mm træbor til at bore et hul på min. 40 mm
Loftskroget har en diameter på 6mm




Bamocks loftsophæng til slyngevugge

BRUGERMANUAL

Monteringsvejledning til justerbart forlængerstrop

Til loftekroget medfølger en forlængerstrop på 63 cm. med syv justerbare løkker.



- 1 Monter forlængerstroppen karabinhagen. Hvis du vil justere på længden skal du tage den ud af karabinhagen og i stedet indsætte et af de syv løkker på karabinhagen.
- 2 Hvis du ikke har en vuggemotor, men vil montere den direkte på fjederen, så skal du lave en løkke om fjederen inden du monterer den på loftekroget.
- 3 Kontrollér at loftekroggen med forlængerstroppen kan klare en belastning på 15 kg. inden du sætter babyen i slyngevuggen. Loftekroget skal slet ikke bevæge sig med en belastning på 15 kg.

Stadig i tvivl, så scan denne video guide om montering af forlængerstroppen



Sikkerhedsinstruktioner



Inden montering af loftekrog skal du altid sikre dig, at loftet er stabilt · Inspicér regelmæssigt loftekroget og det justerbare ophængsstrop · Sikre dig altid at det justerbare ophæng ikke er beskadiget inden brug · Test altid ophænget med 15 kg. inden baby sættes i slyngevuggen · Sikre dig at dit loft kan tåle vægtbelastningen · Loftekrog og det justerbarstrop er ikke noget legetøj · Slyngevuggen må ikke svinges, trækkes eller vugges frem og tilbage eller ude i siderne imens den er på loftekroget · Loftekroget må ikke flyttes med slyngevuggen eller med babyen inde i slyngevuggen · Brug ikke loftekroget eller den justerbare strop, hvis den er beskadiget eller dele mangler · Lad aldrig din baby være ude af syne, når loftekroget anvendes · Hold altid opsyn med børn omkring loftekroget · Mindre børn bør ikke lege i nærheden af loftekroget og ophænget imens slyngevuggen hænger på loftekroget uden opsyn af voksne · Slyngevuggen må kun vugges i en op- og nedadgående bevægelse i loftekroget · Anbefales til indendørs brug · Loftekroget er testet med 15 kg og derfor anbefales denne grænse · Loftekroget er kun testet med bamocks slyngevugge · Vær altid opmærksom på gummibelægningen på karabinhagen, hvis den er slidt indsat krympeflex som erstatning · Ved træloft skal tykkelsen være minimum 12,5 mm · Ved usikkerhed omkring montering af loftekroget anbefales det at kontakte en professionel til montering heraf.


Bamocks ceiling hook for baby hammock

USER MANUAL

Stykliste



Nylon-coated stainless steel O-ceiling hook with a rubber-coated carabiner. Fischer rawplug included.



Adjustable extension strap made of GOTS certified organic cotton.

Installation guide

Mounting ceiling hook on wood

Before mounting the hook on the wood ceiling, make sure that the thickness of the ceiling board is at least 12.5 mm. Also, make sure that the wood ceiling is stable and strong.

- 1 Use a Ø5 mm wood drill bit to bore a hole 40 mm deep into the ceiling. If you don't have a wood drill bit, you can use a screwdriver and a hammer. Gently tap the screwdriver to make a small hole in the wood ceiling where you can screw the ceiling hook in.
- 2 Screw the ceiling hook into the ceiling with the screws until it is securely in place and the screws are no longer visible.
- 3 Attach the carabiner to the ceiling hook by opening it and hooking it into the eye of the ceiling hook.
- 4 Mount the cradle motor or spring on the carabiner. If the distance between the baby hammock and the floor is too high, you can adjust using the included strap. First attach the strap to the motor or spring and then hook it onto the ceiling.

Test the ceiling hook with the carabiner and the baby hammock by placing a weight of 15-20 kg. In the baby hammock. Check if the ceiling hook can support the weight without moving or slipping out of the ceiling. If the ceiling hook moves, tighten the screws or choose another location on the ceiling to mount it.


Installation in concrete ceiling

Before installation in a concrete ceiling, make sure that your concrete ceiling is solid. You will need a concrete drill and an Ø8 concrete drill bit.


- 1 Use an Ø8 concrete drill bit to drill a hole of at least 40 mm.
- 2 Insert the Fischer plug into the hole.
- 3 Screw the ceiling hook into the Fischer plug until the screws are no longer visible. Then attach the carabiner to the ceiling hook.

Ensure that the ceiling hook is securely fastened to the Fischer plug and test the installation with a weight of 15-20 kg to ensure that the ceiling hook does not move at all when tested.

The plate thickness of the wooden ceiling must be at least 12.5 mm.



Use a Ø5 mm wood drill bit to drill a hole of at least 40 mm. The ceiling hook has a diameter of 6mm.




Bamocks ceiling hook for baby hammock

Usermanual

Installation Guide for Adjustable Extension Strap

The ceiling hook comes with a 63 cm extension strap with seven adjustable loops.



- 1 Attach the extension strap to the carabiner. If you need to adjust the length, remove it from the carabiner and insert one of the seven loops onto the carabiner.
- 2 If you do not have a baby hammock motor and want to attach it directly to the spring, make a loop around the spring before mounting it to the ceiling hook.
- 3 Ensure that the ceiling hook with the extension strap can support a load of 15 kg before placing the baby in the swing. The ceiling hook should not move at all with a load of 15 kg.

Still in doubt? Scan and watch this video guide on how to mount the extension strap.



Safety instructions



Before installing the ceiling hook, always make sure that the ceiling is stable · Regularly inspect the ceiling hook and the adjustable suspension strap · Always ensure that the adjustable suspension is not damaged before use · Always test the suspension with a weight of 15 kg before placing the baby in the hammock · Ensure that your ceiling can withstand the weight load · The ceiling hook and the adjustable strap are not toys · The hammock should not be swung, pulled, rocked back and forth, or sideways while hanging from the ceiling hook · The ceiling hook should not be moved with the hammock or the baby inside · Do not use the ceiling hook or the adjustable strap if they are damaged or missing parts · Never leave your baby unattended when using the ceiling hook · Always supervise children around the ceiling hook · Young children should not play near the ceiling hook and the suspension while the hammock is hanging from the ceiling hook without adult supervision · The hammock should only be rocked in an up-and-down motion in the ceiling hook · Recommended for indoor use · The ceiling hook has been tested with a weight of 15 kg, and this limit is therefore recommended · The ceiling hook has only been tested with the Bamocks hammock · Always pay attention to the rubber coating on the carabiner hook. If it is worn, insert shrink tubing as a replacement · For wooden ceilings, the thickness should be at least 12.5 mm · If you are unsure about installing the ceiling hook, it is recommended to contact a professional for installation.

